# AirStash™ Quick Guide

❶

**Insert Memory Card**
Push in fully until “click”
(Push in and release to remove)






❷

**Charge Battery (& USB Drive Access)**
Plug into computer, powered hub, or USB-AC adapter.
When plugged into a computer, drag & drop files like a USB drive.
Please allow up to 2 hours to fully charge AirStash™.

❸

**Wireless Operation**
Press & hold button until indicator light turns on.
(Off: press & hold button until 3 rapid blinks)



❹

**Wireless Connection**
Open your wireless device’s WiFi settings & connect to the AirStash™ network (SSID).




❺

**Wireless Access**
Download & launch app or launch browser & type airstash.net in the address bar.




Maxell Europe Ltd
Revised January 2012
AirStash™ is a registered trademark of Wearable Inc.